




ACM-198C


Return Fitting Ultra Bright LED Light with Remote Control












STEP 1 From existing return fitting, unscrew large, ribbed nut and remove eyeball. Unscrew inner sleeve (Keep these parts in case you remove the return fitting light). **DO NOT UNSCREW EXISTING RETURN FITTING**.

STEP 2 Install return fitting light 1 over the return fitting. Align and secure in place with large nut 2. Do not overtighten.

STEP 3 Insert eyeball **3** (included) at desired angle and secure using ribbed nut **4** (included).

STEP 4 Make sure the electrical cord **5** and transformer **6** are out of the water.

STEP 5 Slide plastic O-ring 7 onto transformer plug. Insert pins into transformer outlet and secure with cap. The transformer 6 should be plugged into a GFCI outlet.



MARNING

- Risk of electrical shock, if instructions are not followed. Connect only to a grounded GFCI outlet that is a minimum of 10 feet (3 m) away from the pool. **DO NOT USE EXTENSION CORDS.**
- Do not let children use this device unsupervised.
- For use on permanent above-ground pools only.
- Do not use the light if the lens, transformer or cord is damaged.

WINTER STORAGE: Freezing weather may damage light fixture. Disconnect light and remove from the pool. Store in dry space at room temperature.

NOTE: See Remote Control Instructions for Operating and Pairing Remote with ACM-198C Pool Light