C INSTRUCTIONS FOR DRILLING HOLE INTO SKIMMER WITHOUT PRE-DRILLED HOLE

STEP 1 Cut out template along dotted line.


7/8"
(2,223 cm)

20mm hole

5/8"
(1,588 cm)

5-1/8" (13,018 cm)

TEMPLATE (This side up)

3-1/4" (8,255 cm)

STEP 2 Line template up with the top edge of skimmer. The edge of the template **MUST** be flush with the side edge of the skimmer.

*Align template with top edge of skimmer.*

TEMPLATE (This side up)

Template MUST be flush with edge of skimmer.

STEP 3 Tape template securely in place.

STEP 4 Making sure that center point is aligned, carefully drill hole using a 20 mm hole saw.

TEMPLATE (This side up)

Remove template and follow instructions for installation of skimmer light (A)

CPI
Champlain Plastics, Inc.

ACM-197, ACM-197C
Skimmer Cover Plate with Ultra Bright LED Light

TYPE OF INSTALLATION:

A
FOR INSTALLATION ON SKIMMER WITH PRE-DRILLED HOLE

MAX
MIN

B
FOR INSTALLATION ON SKIMMER WITHOUT PRE-DRILLED HOLE

MAX
MIN

C
INSTRUCTIONS FOR DRILLING HOLE INTO SKIMMER WITHOUT PRE-DRILLED HOLE

TOOLS NEEDED

20mm

⚠ WARNING

- Risk of electrical shock, if instructions are not followed. Connect only to a grounded GFCI outlet that is a minimum of 10 feet (3 m) away from the pool. **DO NOT USE EXTENSION CORDS.**

- Do not let children use this device unsupervised.

- For use on permanent above-ground pools only.

- Do not use the light if the lens, transformer or cord is damaged.

c(UL)us

WINTER STORAGE: Freezing weather may damage light fixture. Disconnect light and remove from the pool. Store in dry space at room temperature.

NOTE: Operating and Pairing Remote with Pool Lights Instructions included with ACM-197C only.

# A FOR INSTALLATION ON SKIMMER **WITH** PRE-DRILLED HOLE

Pre-drilled hole

STEP 1 Thread electrical cord ❶ through the pre-drilled hole ❷ in the skimmer as shown leaving just enough cord to maneuver the cover plate ❸.

Interior of skimmer

STEP 2 Slide factory installed grommet ❹ down the cord and push through the hole in the skimmer so that the grommet plugs up the hole from both sides. *NOTE: Grommet is not watertight.*

STEP 3 Snap cover plate ❸ in place.

B FOR INSTALLATION ON SKIMMER **WITHOUT** PRE-DRILLED HOLE

Channel

STEP 1 On the backside of the cover plate ❶ remove the screw ❷ holding the electrical cord ❸ in place.

STEP 2 With the cord ❸ well out of the way, use an exacto knife to carefully cut out the channel in the upper lip of the cover plate ❶. Pass the cord ❸ through the channel.

STEP 3 Snap cover plate ❶ in place.

Step 4
FOR BOTH TYPES OF INSTALLATION:

Make sure the electrical cord and transformer ❺ are out of the water. Slide plastic O-ring ❻ onto transformer plug. Insert pins ❼ into transformer outlet and secure with cap.

STEP 5 The transformer should be plugged into a GFCI outlet.

MAX

MIN